






# TT-3500/ BI-3500 SPARE PARTS LIST



- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1) SE-FAN-CB-35A - FAN        | 6) SE-503-001-000 - KNOB          |
| 2) SE-SR-CB-35A - SENSOR      | 7) SE-FOIL-CB-35A - CONTROL PANEL |
| 3) SE-COIL-CB-35A - COIL      | 8) SE-CTRL-CB-35A - LED BOARD     |
| 4) SE-PCB-CB-35A - MAIN BOARD | 9) CERAMIC GLASS                  |
| 5) SE-EMI-CB-35A – EMI PCB    | 10) SE-1GBT-CB-35A - 1GBT BOARD   |