

Blixer® 2 / 3 / 4 / 4 V.V. / 5 / 5V.V.

Safety and Operating Instructions
安全与操作说明

Hang on the wall.
挂在墙上。



robot coupe®
www.robot-coupe.com

Control Panel 控制面板



Power Off Button
关机按钮



Power On Button
开机按钮



Pulse button
脉冲按钮




Blixer 4 / Blixer 5
2-speed Selector switch
双速选择开关




Blixer 4 V.V. / Blixer 5 V.V.
Speed variator
变速器

Switching on and using the mixer 开启和使用搅拌器




Cleaning and maintenance 清洁与维护




Bowl / 碗

BLIXER 3 / 4
Blade / 刀片



O-ring (seal) / O 形圈 (密封件)



Safety 安全性

