



INSTRUCTION MANUAL

GRC-23 Rice Cooker



Model GRC-23

Owners Manual

Specifications:

Rating – 120/220VAC, 50/60HZ. 1600W

Before Using for the first time:

- Read ALL instructions carefully
- Remove all packaging
- Clean appliance with a clean, damp cloth.
- DO NOT IMMERSE IN WATER



Guidelines for safe use

When using your Rice Cooker, the following basic safety precautions should be followed:

- Do not touch hot surfaces. Use handles or knobs.
- Do not move unit when power is on.
- Unplug when not in use.
- Unplug and allow cooling prior to cleaning.
- Do not use if power cord is damaged in any way.
- Do not use outdoors.
- Do not let power cord hang over edge of counter or table where it might get caught.
- Do not place on or near an oven or any heat source as this may damage the unit.
- Do not use the unit for other than intended use.
- Keep this manual safe and in a convenient location.

Cleaning

- DO NOT IMMERSE THE UNIT IN WATER AT ANY TIME
- Ensure the unit is unplugged and cool before cleaning.
- Clean the outside with a damp cloth.
- Clean the inner bowl with hot soapy water and a soft brush. Do not use any metal tools or scouring material.
- Harsh cleaning chemicals may damage the appearance and performance of this unit.

Operating Instructions

1. Use the measuring cup to provide the desired quantity of rice. As a guide, one cup of rice is sufficient for one person.
2. Thoroughly wash the rice in several changes of water and drain. Failure to do so may affect the quality of the cooked rice and cause a build up of steam.
3. Place the rice in the inner bowl. Add water to the corresponding level marked on the bowl, i.e. for 4 cups of rice fill the water up to level 4.
4. Put the inner bowl into the rice cooker. Please ensure there is no rice on the outside of the bowl and it is dry.
5. Cover with lid.
6. Plug in unit. The yellow "keep warm" light will come on.
7. Press the switch and the red "cook" light will come on, indicating the rice is starting to cook.



8. When the rice is cooked, the unit will automatically switch to the "Keep Warm" function. Leave the lid on for 10 minutes as the unit finishes the cooking of the rice by steaming.
9. Remove the lid and stir the rice. It is now ready to eat. Consume the stirred rice within one hour.
10. The Holding period should not exceed 2 hours.
11. After use, remove plug from power outlet.

Other Important Points

- To allow the machine to function correctly, do not immediately switch the unit back to the cooking setting after the completion of a cook cycle
- Always use heat resistant gloves when removing the inner bowl from the unit
- Certain kinds of rice may cause a build up of steam within the unit, when this occurs simply lift the lid to allow the steam to escape
- Do not reheat cooked rice in the rice cooker
- Do not lift the lid during the "Keep Warm" period
- Do not use sharp objects inside the bowl as this may damage the nonstick coating.

Contact Us:

FOR WARRANTY, SERVICE OR PARTS, PLEASE CONTACT:
Asbury Service Warranty & Parts
Toll Free: 1.877.368.2797

Or visit:

www.asburyfoodservice.com



**Read & Keep
these instructions**



Indoor use only



Do not discard



Fort Lauderdale, FL 33331, U.S.A.

Phone:(877) 368-2797 · Fax:(954) 202-7337